# **TOTAL STATION**

# R-2500 N SERIES

R-2501N,R-2502N R-2503N,R-2505N

# INSTRUCTION MANUAL Basic Procedures

#### TI Asahi Co.,Ltd.

International Sales Department 4-3-4 Ueno Iwatsuki-Ku,Saitama-Si Saitama,339-0073 Japan Tel, +81-48-793-0118 Fax, +81-48-793-0128

E-mail: international@tiasahi.com



# **CONTENTS**

GENERAL	
Contents	1
Exemption clause	4
Copyright	4
Precautions regarding safety	5
Warning	5
Usage Precautions	8
	· ·
1. BASIC OPERATION	11
1.1 Names of parts	11
1.2 Standard equipment	12
1.3 Unpacking and packing	12
1.4 Removing and attaching the Battery	12
1.5 How to charge the Battery	13
1.6 External connections	15
1.2 Standard equipment 1.3 Unpacking and packing 1.4 Removing and attaching the Battery 1.5 How to charge the Battery 1.6 External connections  2. DISPLAY AND KEYBOARD 2.1 Display and keyboard 2.2 Operation keys 2.3 Function keys 2.4 Alphanumeric input 2.5 LD POINT, Laser pointer	
2. DISPLAY AND KEYBOARD	17
2.1 Display and keyboard	17
2.2 Operation keys	17
2.3 Function keys	18
2.4 Alphanumeric input	20
2.5 LD POINT, Laser pointer	20
2.5 ED 1 Onv1, Easer pointer	20
3. PREPARATION FOR SURVEYING	21
3.1 Centring and Levelling of the Instrument	21
3.2 Laser plummet	21
3.3 Levelling with circular vial	23
3.4 Levelling with the electronic vial	23
3.5 Eyepiece adjustment	24
3.6 Target sighting	25
3.7 Attachment and detachment of tribrach	29
4. TURNING THE POWER ON	20
	<b>30</b>
4.1 Turning the power on and off	30
4.2 Adjusting LCD contrast	30
4.3 Adjusting illumination brightness	31
4.4 Adjusting reticle illumination	31

5. ANGLE MEASUREMENT	32
5.1 Measuring an angle	32
5.2 Resetting the horizontal angle to 0	32
5.3 Holding the horizontal angle	33
5.4 Inputting an arbitrary horizontal angle	33
5.5 Displaying the slope % of the vertical angle	34
5.6 Changing the horizontal angle from clockwise to counter clockwise	35
6. DISTANCE MEASUREMENT	36
6.1 Target setting	36
6.2 Distance measurement	37
6.3 Quick mode	38
7. CORRECTION MODE	39
7.1 Changing the target constant	39
7.2 Changing the temperature	40
7.3 Changing the atmospheric pressure	41
7.4 Changing the ppm value	42
7. CORRECTION MODE 7.1 Changing the target constant 7.2 Changing the temperature 7.3 Changing the atmospheric pressure 7.4 Changing the ppm value  8. INITIAL SETTING 8.1 Overview 8.2 Entering the mode for initial setting 1	
8. INITIAL SETTING	43
8.1 Overview	43
8.2 Entering the mode for initial setting 1	43
8.3 Entering the mode for initial setting 2	43
8.4 Entering the mode for initial setting 4	43
8.5 Entering the mode for initial setting 5	44
8.6 Entering the mode for setting of data and time	44
8.7 Example of changing an initial setting content	
(selection of atmospheric correction)	45
8.8 Initial setting 1	46
8.9 Initial setting 2	47
8.10 Initial setting 4	49
8.11 Initial setting 5	50
8.12 Setting of date and time	50
9. ACCESSING THE FUNCTIONS	52
9.1 Accessing by help key	52
9.2 Accessing by 007	52
Instrument setting items	53

10. DATA COLLECTOR	54
11. CHECKS AND ADJUSTMENTS	54
11.1 Plate level	54
11.2 Circular vial	55
11.3 Vertical reticle	56
11.4 Perpendicularity of line of sight to horizontal axis	57
11.5 Vertical 0 point error	58
11.6 Laser plummet	58
11.7 Offset constant	58
11.8 Beam axis and line of sight	59
11.9 The EDM beam axis	60
12. APPENDIX 12.1 Warning and Error Messages 12.2 Atmospheric correction 12.3 hPa and mmHg conversion table 12.4 Error when no atmospheric correction is made	
12. APPENDIX	61
12.1 Warning and Error Messages	61
12.2 Atmospheric correction	62
12.3 hPa and mmHg conversion table	62
12.4 Error when no atmospheric correction is made	63
12.5 Atmospheric refraction and earth curvature correction	64
12.6 Distance range	65
12.7 Specifications	66
CAS CONTRACTOR OF THE CONTRACT	
12.6 Distance range 12.7 Specifications	
13. Notice to the user of this product	69
13.1 Specifications of Laser Radiation	69
13.2 The following labels are affixed to and must remain	
attached to this laser product.	69
13.3 Caution to maintain the safety in compliance with the standard	70

Before using this product, be sure that you have thoroughly read and understood this instruction manual to ensure proper operation. After reading this manual, be sure to keep in a convenient place for easy reference.

# **Exemption clause**

- 1) TI Asahi Co.,Ltd. (TIA) shall not be liable for damage caused by Acts of God, fire, alteration or servicing by unauthorized parties, accident, negligence, misuse, abnormal operating conditions.
- 2) TIA shall not be liable for changes or disappearance of data, loss of company profit or interruption of company operation incurred by the use of this product or malfunction of it.
- 3) TIA shall not be liable for damage caused by usage not explained in the instruction manual.
- 4) TIA shall not be liable for damage to this product caused by other equipment connected to this product.



Copyright © 2013 TI Asahi Co., Ltd..

#### **All Rights Reserved**

TI Asahi Co.,Ltd. is the sole proprietor of the PowerTopoLite software.

The PowerTopoLite software and publication in whole or parts thereof, may not be reproduced in any form, by any method, for any purpose.

TI Asahi Co., Ltd. makes no warranty, expressed or implied, including, but not limited to, any implied warranties or merchantability or fitness for a particular purpose, regarding these materials and makes such materials available.

# PRECAUTIONS REGARDING SAFETY

# **Safety precautions (Must be followed)**

The following items are intended to prevent possible injury to the user or other people and/or damage to the instrument before it occurs. These safety precautions are important to the safe operation of this product and should be observed at all times.

#### **Distinctive displays**

The following displays are used to distinguish precautions by the degree of injury or damage that may result if the precaution is ignored.



#### WARNING

Items indicated by this sign are precautions which, if ignored, would result in serious injury.



# **CAUTION**

Items indicated by this sign are precautions which if ignored may result in injury or material damage.

- Here "injury" refers to injuries such as cuts, burns or electric shock, of which treatment will not likely require hospitalization or long-term attention.
- "Material damage" refers to damage to facilities, buildings, acquired data, etc.

Before using this product, be sure that you have thoroughly read and understood this instruction manual to ensure proper operation. After reading this manual, be sure to keep it in a convenient place for easy reference.

This instrument complies with the protection requirement for residential and commercial areas. If this instrument is used close to industrial areas or transmitters, the equipment can be influenced by electromagnetic fields.

Quick Reference Guide provided in your carrying case contains the following items:

- 1. Basic Procedures
- 2. PowerTopoLite Operating Procedures



# WARNING

⚠ Do not stare into the laser beam directly as this may result in damage to your eyes.

R-2500N is a Class IIIa (3R) Laser product. Do not look into the laser radiation aperture directly as this may result in damage to your eyes.

Never use the telescope to view intense light such as direct sunlight or sunlight reflected through a prism as this may result in loss of sight.

⚠ Do not disassemble, modify or repair this product as there is a risk of laser radiation.

- ⚠ Do not aim the laser beam at a person as it is harmful to the eyes and body. Receive the examination treatment by the doctor when the eyesight or body trouble is doubted by any chance.
- Electro-Magnetic Compatibility (EMC):
  This instrument complies with the protection requirement for residential and commercial areas. If this instrument is used close to industrial areas or transmitters, the equipment can be influenced by electromagnetic fields.
- Do not use this product in a coal mine, in a location where there is coal dust, or near flammable material as there is a risk of explosion.
- Do not disassemble, modify or repair this product as there is a risk of fire, electric shock and burn injury. If you think the product requires repair, contact the retail outlet where you purchased it or an authorized repair site.
- Do not charge the BP07 Battery with any battery charger other than the BC05 battery charger as it entails a risk of fire or burn injury from the battery bursting into flames due to possible differences in voltage or polarity.
- Do not use a damaged electric cord plug or loose electric outlet when charging as there is a risk of fire or electric shock.
- Do not charge the battery while covered by clothes or similar items as there is a risk of fire if the clothes ignite.
- Do not use the battery or charger when wet as there is a risk of fire and burn injury due to short-circuit.
- To prevent making short-circuit when removing the battery and charger from the case and storing them, apply electrically resistant tape to the poles of the battery. Storing the battery and charger as it is may result in fire or burn injury due to short-circuit.
- Do not throw the battery into fire or expose it to heat as there is a risk of injury if it explodes.



# **CAUTION**

- For your safety, perform the initial and periodical inspection as well as when the instrument is fixed and adjusted.
- When the laser beam enters eyes, an unexpected accident might be caused by blink of eyes.
- ⚠ Do not place the laser product at a height where its laser beam may hit the eyes of car drivers and pedestrians.
- Do not place the laser product at a place where its laser beam may hit a reflecting object such as a mirror or a glass window. The reflection beam of the laser is also harmful to the human body.
- When not performing measurement, cut off the power supply or shade the objective lens with objective cap to prevent the instrument emitting the laser beam.
- Keep the laser product in a place where persons, who do not have the product knowledge, such as children, can not touch it by mistake.
- Before disposing of the instrument, destroy its power supply mechanism to prevent it from emitting the laser beam.
- Do not remove the handgrip without good reason. If it does come off, be sure to attach it securely to the instrument with screws. If it is not fastened securely, the instrument may fall when you use the handgrip, leading to possible injury.
- Do not short the poles of the battery or charger as there is a risk of injury or fire.

- Do not touch any fluid which may leak from the battery as there is a risk of chemical burn injury or reaction.
- Do not insert or remove the electric plug with wet hands as there is a risk of electric shock.
- Do not use the case to stand on as it is slippery and unstable and may cause you to fall, resulting in possible injury.
- Make sure the tripod itself and the instrument on the tripod are both installed securely as insecure installation may cause the tripod to fall over or the instrument to drop, resulting in possible injury.
- Do not carry the tripod with the metal shoe pointing toward another person as it may injure him/her.
- The instrument contains a rechargeable battery and a battery charger.
- It may be illegal to dispose the battery at the end of its useful life.
- Check with your local solid waste officials for details for recycling.



# Usage precautions

Surveying instruments are high-precision instruments. In order to assure that the Electronic Total Station R-2500N series product which you have purchased will provide long-lasting maximum performance, the precautions in this manual must be followed. Make sure to follow these instructions and use this product properly at all times.

# [Solar observation]



## WARNING

Never view the sun directly using the telescope as this may result in loss of sight. Never point the objective lens directly at the sun as this may damage internal components. When using the instrument for solar observation, be sure to attach the specially designed solar filter (MU64) to the objective lens.

# **▲** [Laser beam]

Do not stare into the laser beam. R-2500N is a Class IIIa (3R) Laser product.

# [EDM axis]

The R-2500N series EDM is a red visible laser beam and the beam diameter is very small. The beam is emitted from the objective centre. The EDM axis is designed to coincide with the telescope sight axis (but both axes may deviate slightly because of intense temperature changes and a long time lapse).

# [Target constant]

Confirm the Target Constant of the instrument before measurement.

If a different constant is to be used, use the correct constant of the target. The constant is stored in the instrument's memory when turned off.

# [Reflectorless and reflector sheet]

- Reflectorless (Non-Prism)
  - The measurement range and accuracy of the Reflectorless mode are based on the condition that laser beam is emitted perpendicular to the white side of a Kodak Gray Card. The measurement range may be influenced by the shape of the target and its environment. There is a possibility that the range may vary when the target does not satisfy the conditions above at survey work.
- There is a possibility that correct distance measurement may not be performed by dispersion or reduction of laser beam when the laser beam comes into the target from a diagonal angle.
- There is a possibility that the instrument may not be able to correctly calculate out the distance when receiving reflected laser beam from forth and back directions in case of measuring the target on the road.
- There is a possibility that synthesized values are calculated and the distance may become longer or shorter than the actual one when the operator measures the target of slope or sphere or rugged shape.
- There is a possibility that the instrument may not be able to correctly calculate out the distance by collecting the reflected laser beam from a man or a car that comes and goes in front of the target.

- There is a possibility that the distance may not be correctly measured when measuring a target in the direction where there is a reflecting object (mirror, stainless board, white wall, etc.) or under too strong sunlight.
- In a situation where high accuracy may not be expected, perform the measurement by Reflector sheet or Prism.
- When using reflector sheet, set the reflector sheet to have its surface to be approx. vertical to the aiming line. If it is positioned not to be approx. right angle, there is a possibility that correct distance measurements may be impossible by dispersion or reduction of laser beam.

In the following environments, the distance may not be possible to be measured; there is a reflecting thing (mirror, stainless board, white wall, etc.) in the direction of the target, and under too strong sunlight

# [Battery & charger]

- Do not use any battery or battery charger that is not approved by Pentax as it entails a risk of damaging the instrument.
- If water should happen to splash on the instrument or the battery, wipe it off immediately and allow it to dry in a dry location. Do not put the instrument in the case until it is completely dry as this may result in damage to the instrument.
- Turn off the power when removing the battery from the instrument as removing the battery while the power is still on may result in damage to the instrument.
- The battery mark displayed on the instrument is only an estimation of remaining battery power and is not completely accurate. Replace the battery quickly when it is about to run out of power as the time a battery lasts on one full charge differs depending on conditions of ambient temperature, and the measurement mode of the instrument.
- Confirm the battery level remaining before operating.

# [LD POINT, laser pointer]

When you make a correct direction using the "LD POINT", aim the laser beam at the wall and mark the centre and then confirm the discrepancy between the reticle centre and the marked point beforehand.

# [Storage and operating environment]

- To prevent making short-circuit when removing the battery and charger from the case and storing them, apply electric resistant tape to the poles of the battery. Storing the battery and charger as it may result in fire or burn injury due to short-circuit.
- Avoid storing the instrument in places subject to extreme high, low or radically fluctuating temperature. (Ambient temperature range during use: -20° C to +50° C)
- Distance measurements may take longer when atmospheric conditions are poor such as when heat shimmer occurs. When storing the instrument, always put it in its case and avoid storage in dusty location or location subject to vibration or extreme heat or humidity.
- Whenever there is a sharp temperature difference between the instrument's storage and usage environment, allow the instrument to adjust to the environment for an hour or more before using it. Make sure to protect the instrument from the sun if the location is subject to intense direct sunlight.
- During surveys for which the survey precision or atmospheric measurement method has been defined, measure the atmospheric temperature and pressure separately and enter those values rather than using the Automatic Atmospheric Correction function.

- The battery should be charged approximately once per month if the instrument is to be stored for an extended period of time. The instrument should also be removed from its case occasionally and aired out.
- In addition to these precautions, be sure to handle the instrument properly at all times following the descriptions given in the various sections of this manual to assure safe and proper measurements.

# [Transporting and carrying the instrument]


- Be careful to protect this instrument from shock of impact and excessive vibration which may result in damage during transportation and shipment.
- When transporting the instrument, always put it in the case and wrap shock absorbing material around it and be sure it is handled as "FRAGILE".

# [Checks and repairs]

- Always check the instrument before beginning work and check that the instrument is
  maintaining the proper level of precision. Pentax bears absolutely no responsibility for
  damages due to survey results obtained from surveys conducted without an initial
  instrument check.
- Never disassemble the instrument, battery or charger, even if you do detect an abnormality, as there is a risk of fire or electric shock due to short-circuit. If you think the product requires repair, contact the retail outlet where you purchased it or an authorized repair site.

# 1. BASIC OPERATION

# 1.1 Names of parts



# 1.2 Standard equipment

- Instrument
- Carrying case
- BP07 battery
- BC05 battery charger
- AC05 AC adapter
- Power supply cord
- Plumb bob
- · Hexagonal wrench
- Adjusting pin
- Screwdriver
- · Rain cover
- Quick Reference Guide
- CD-ROM (Basic operation & Special Functions manual)
- USB cable
- · SD card

# 1.3 Unpacking and packing

# [Unpacking the Instrument from the case]

- ① Set the case down gently with the lid facing upwards.
- ② Open the latches while pressing down on the lock (safety mechanism) and open the lid of the case.
- ③ Remove the instrument from the case.

# [Packing the instrument in the case]

- ① Make sure the telescope is fairly levelled and lightly tighten the telescope clamp screw.
- ② Line up the housing marks (round yellow marks on the instrument) and tighten the upper and lower clamp screws.
- ③ With the housing marks are facing upwards, set the instrument gently in the case without forcing it. Close the lid to the case and secure the latches.

# 1.4 Removing and attaching the Battery

# [Removing the Battery]









BatteryA (upside battery)

- ①The switch of a left-hand side side is made to slide upwards, and a cover is opened.
- ②It removes shifting a battery upwards.

# BatteryB (lower battery)

- ① Rotate the knob above the battery pack counter clockwise.
- $\ensuremath{\textcircled{2}}$  Lift up the battery pack and remove it from the instrument.

# [Attaching the Battery]









#### BatteryA (upside battery)

- ①The switch of a left-hand side side is made to slide upwards, and a cover is opened.
- ②It attaches putting a battery in slanting down one.

#### BatteryB (lower battery)

- ① Place the channel on the bottom of the battery pack.
- ② Onto the protrusion of the instrument and push the battery pack down into place.
- ③ Turn the knob clockwise.

# 1.5 How to charge the Battery

The R-2500N comes with two lithium-ion rechargeable batteries with a typical operating time between 8 to 10 hours.

#### Specifications

Battery Type: Lithium ION

+6.2VDC to 8.4VDC Voltage:

2500mAH Capacity:


#### [Battery Charger]

AC Adapter

Input: 100-240VAC ~50/60Hz 1.7A

Output: 19.0VDC @ 3.16A

# [Charging the battery]



- Plug the AC cord to AC Adapter
- Plug in AC Adapter to Battery Charger
- Plug the AC wall battery charger into the wall socket and power LED turns ON
- Place your battery in charger bay correctly
- Wait until battery LED indicator turns GREEN for a full charge

LED	Description
NONE	Battery is not seated correctly
GREEN	Battery is fully charged
RED	Battery is being re-charged
Flashing RED	Charge error or bad battery



A fully discharged battery will take approximately 2 hours to fully charge and may not light the LED status indicator when first mounted.

# [Battery Installation and Replacement]



Removing the battery in use will cause the R-2500N to restart or turn OFF. Use the battery status indicator in data collection software to confirm which battery is "in use" before hot-swapping batteries.

- Press button to open battery door compartment
- Use the guide to slide the battery into the R-2500N
  - Swivel the battery door compartment up and push from the bottom until it latches completely

What you need to know	
Can I remove one of the batteries while the R-2500N is in use?	Before battery removal, use data collection software to check which battery is in use. Remove the battery not in use
How long does it take to charge a battery?	It takes 2 hours to fully charge a battery
How do I know if battery is fully charged?	Battery bay LED turns Green when fully charged




Contact a Recycling Center to ensure proper disposal of lithium-ion Batteries.

#### 1.6 External connections

[Inserting SD card]

- (1) Open the SD & USB slot cover.
- (2) Insert the SD card(The side with terminal should face the instrument and the cut-off corner should be up.)
- (3) Insert the SD card to the end. Be sure not to press the card too hard.
- (4) After the SD card is inserted, close the SD & USB slot cover completely.



#### [Removing SD card]

- (1) Open the SD & USB slot cover.
- (2) Lightly press the SD card slot then release yourself from there.
- (3) The SD card pops up.
- (4) After the SD card is removed, close the SD & USB slot cover completely.



# **CAUTION**

- Be sure to turn the power off before inserting and removing the SD card.
- Be sure to close/open the SD & USB slot cover and insert/remove the SD card indoors.

#### [Suitability of SD card]

- SD card and SD logo is registered trademark.
- The SD cards listed in the following table have been tested by us and it has been confirmed that the SD cards can be used with the R-2500N series.

This test has been done with only the Pentax R-2500N series Total Station, but no other Pentax

Total Stations. When using with other Pentax Total Stations, please contact us to confirm if it works properly.

Also it has been confirmed that the models mentioned in the following table can be used with the R-2500N series Total Station, but it has not been confirmed whether other brand SD cards, not mentioned here, can be used with the R-2500N series Total Station.

Please note that the test has been done by us and it is not meant that each SD card manufacturer guarantees that the SD cards can be used with the Pentax R-2500N series.

#### SD (micro SD) Card

Maker	Model	Capacity
Toshiba	SD-C01GTR	1GB
Toshiba	SD-MD001GA (microSD)	1GB
Panasonic	RP-SDM01GL1A	1GB

Be sure to use the adaptor when using a microSD.

- Regardless of the information here, be aware that all the SDHC cards can't be used with the R-2500N Total Stations.
- Test item: The following has been done according to our test standard.
  - ① When data is being sent (with connecting USB), it is necessary to be able to refer to information in the SD card from PC and to operate the file.
  - ② When writing / reading text, it is necessary to be able to read/write text file.


#### [Connecting USB cable]

- (1) Open the SD & USB slot cover.
- (2) Insert the USB connector into the USB port in the right direction.
- (3) After the USB cable is removed, close the SD & USB slot cover completely.




#### **CAUTION**

- Be sure to turn the power off before inserting/removing the USB cable.
- Be sure to open/close the SD & USB slot cover and insert/remove the USB cable indoors.



# 2. DISPLAY AND KEYBOARD

# 2.1 Display and keyboard



# 2.2 Operation keys

Key	Description
[POWER]	ON/OFF of power supply.
[ESC]	Returns to previous screen or cancels an operation.
[ILLU]	Turns the illumination of the LCD display and telescope reticle on and off.
[ENT]	Accepts the selected (highlighted) choice or the displayed screen value.
[LASER]	Displays the laser plummet, electronic vial function, and the LD point screen when you push the laser plummet/electronic vial key. (Refer to "2.5 LD POINT, Laser pointer", "3.2 Laser plummet", and "3.4 Leveling with the electronic vial").
[Alphanumeric]	At the numerical value screen, the numerical value and the sign "." displayed are input. The English characters printed right under numeric of each key are input.
[HELP]	Pressing [ILLU]+[ESC] key causes a help menu to appear in A MODE or B MODE or causes a help message to appear.

# 2.3 Function keys

Display	F. Key	Description
MODE A		
[MEAS]	F1	Pressing this key one time measures the distance in normal mode. Another measurement type can be selected by InitialSetting 2.  Pressing this key twice measures the distance in coarse mode. Another measurement type can be selected by initial setting 2.
[TARGET]	F2	Switches the target. REFLECTORLESS / SHEET / PRISM
[0 SET]	F3	Resets the horizontal angle to 0° 0' 0" by pressing twice.
[DISP]	F4	Switches the display composition in the order "H.angle/H.dst./V.dst.", "H.angle/V.angle/S.dst." and "H.angle/V.angle/H.dst./S.dst./V.dst.".
[MODE]	F5	Switches the screen between MODE A and MODE B.
MODE B		System
[S.FUNC]	F1	PowerTopoLite Special Functions.
[ANG SET]	F2	Brings up the angle setting screen for setting angle-related parameters.  (H.ANGLE /%GRADE, H.ANGLE INPUT and L/R EVERSE)
[HOLD]	F3	Pressing this key twice retains (holds) the horizontal angle shown on the display.
[CORR]	F4	Brings up the screen for changing the target constant, temperature, pressure setting.
[MODE]	F5	Switches the screen between MODE A and MODE B.

# [Other functions]


<u> </u>	F1	Moves the cursor to the left.	
	F2	Moves the cursor to the right.	
[ ① ]	F3	Moves the cursor up.	
[ 1	F4	Moves the cursor down.	
	F1	Goes back five items on the screen.	
[ \( \nabla \)]	F2	Gose forward five items on the screen.	
[RETICLE]	F3	Changing the reticle illumination when pressing illumination	
		key.	
[LCD]	F4	Changing the LCD contrast when pressing illumination key.	
[ILLU]	F5	Changing the LCD illumination when pressing illumination	
		key.	
[CLEAR]	F5	Clear the figure.	
[SELECT]	F5	Open the selection window.	

# [How to move the menu number]

# Example:

The cursor is located at Menu 1.

Press the numeric key 0 and 2 to move to Menu 2 or press [F4][ ↓ ].





#### 2.4 Alphanumeric input

The point name is input by the alphanumeric keys as following.

Letter under key	Letter & figure order to input
	[@] [. ] [_] [-] [:] [/] [0]
PQRS	[P] [Q] [R] [S] [p] [q] [r] [s] [1]
TUV	[T] [U] [V] [t] [u] [v] [2]
WXYZ	[W] [X] [Y] [Z] [w] [x] [y] [z] [3]
GHI	[G][H][I][g][h][i][4]
JKL	[J] [K] [L] [j] [k] [l] [5]
MNO	[M] [N] [O] [m] [n] [o] [6]
	[ ][?][!][_][^][ ][&][7]
ABC	[A] [B] [C] [a] [b] [c] [8]
DEF	[D] [E] [F] [d] [e] [f] [9]
	[.][,][:][#][(][)]
	[+][-][*][/][%][=][<][>]
	PQRS TUV WXYZ GHI JKL MNO

# 2.5 LD POINT, Laser pointer

The Laser pointer function turns the laser beam on continuously to become the aiming point so that visual confirmation is possible.


- ① When the [F2][LD POINT] key is pressed after pressing the [Laser] key, the Laser pointer function is turned on. The Laser indicator is turned on and the "\* mark on the left of the screen blinks while the Laser pointer function is operating.
- ② If the [Laser] key is pressed and the [F2][LD POINT] key is pressed while the Laser pointer function is operating, the Laser pointer function is turned off.
- The beam of the sun is strong and visual confirmation is difficult in daytime when outdoors.
- The laser beam is designed not to be able to observe through the telescope.
- Please visually align the laser beam to the target and mark the centre. Confirm the alignment (horizontal and vertical) before measuring when performing accurate work like stake out when using the Laser pointer function. Also refer to "11.9 The EDM beam axis".
- Please do not look at the laser source of beam directly.

# 3. PREPARATION FOR SURVEYING

# 3.1 Centring and Levelling of the Instrument

# [Setting up the instrument and the tripod]

- ① Adjust the tripod legs so that a height suitable for observation is obtained when the instrument is set on the tripod.
- ② Hang the plumb bob on the hook of the tripod, and coarse centre over the station on the ground. At this time, set the tripod and fix the metal shoes firmly into the ground so that the tripod head is as levelled as possible.
- ③ If the tripod head is mis-levelled by the action of fixing the metal shoes into the ground, correct the level by extending or retracting each leg of the tripod.



# 3.2 Laser plummet

# [Laser plummet model]

The laser plummet is not set to be ON at factory shipping. The laser plummet operation of power supply ON can be set by command No.520, LD PLUM. & E.VIAL. For using Command number, refer to "9.2 Accessing by 007".

# [For the Detaching type laser plummet equipment model]

Turn on the laser plummet function by pushing the [Laser] key.

Match the position with the leveling screw so that the laser mark coincides with the ground mark.


# [For the Shift type laser plummet equipment model]

- Turn on the laser plummet function by pushing the [Laser] key.
- Match the position by the tripod so that the laser mark coincides with the ground mark.
- The centring knob is loosened, and the upper plate is pushed by the tip of a finger, and a centre mark is matched to the ground mark.
- Tighten the centring knob.
- Loosen the horizontal clamp screw, rotate the instrument by 90°, and confirm the vial of the circular vial is at the centre position.
  - Correct the vial with the leveling screw when the vial comes off from the centre position.


# [Brightness adjustment of laser]

Sometimes the state of the surface of the ground mark or a surrounding environmental does not allow observing the laser spot easily. Please adjust the brightness of the laser if necessary.

If the [Laser] key is pressed, the brightness adjustment screen of the laser plummet device, is displayed.




The Laser plummet becomes darker or brighter by pressing  $[F1][ \Leftrightarrow ] / [F2][ \Rightarrow ]$  key.




#### \*\*R-2501N,R-2502N

The adjustment is completed with the [ENT] key and it returns to electronic vial screen.



#### **%**R-2503N,R-2505N

The adjustment is completed with the [ENT] key and it returns to RED MARK & LD PLUM. Settings screen.



- The brightness adjustment step of the laser is 10 steps.
- The laser plummet spot can become difficult to see in bright sunlight which makes it difficult to perform the occasional check. In this case, use your foot or the carrying case to make a shadow over the laser position.
- The laser plummet is adjusted to be within  $\pm 0.5$ mm at the instrument height of 1.5m at factory shipping.
- Please double check the amount of the gap
   (direction of X and Y direction) by laser plummet
   with the amount of the gap by plumb bomb etc.
   When working accurately you should put out a
   perpendicular direction using the laser plummet
   function.
- Please do not look at the laser source of beam directly.



# 3.3 Levelling with circular vial

Tripod is adjusted according to the following points by extending or contracting the legs so that the bubble of the Circular vial goes to the centre of the circle.


- Shorten the leg at the side of the bubble or extend the leg opposite of the bubble to position the bubble in the centre of the vial circle.
- All three legs are extended or contracted until the bubble is in the centre.

  During this process, the foot is not placed on the tripod leg point and the position of the tripod points do not change.

# 3.4 Levelling with the electronic vial


#### [Electronic vial screen]

① If the [Laser] key is pushed, it becomes a display screen for the Electronic vial.



\*\*R-2501N,R-2502N

② It returns to the former screen by the [ESC] key.




# [Levelling]

- ① Rotate instrument horizontally and make two Leveling screws arbitrarily chosen parallel to the display.
- ② Turn on the Electronic vial function by pushing the [Laser] key.

  Put the bubble of the Circular vial in the centre of the circle when the display shows "TILT OVER".
- ③ Turn two Leveling screws arbitrarily chosen in an opposite direction mutually and put the vial of the horizontal Electronic vial in the centre.

  (Figure A)
- ④ Put the bubble of the lengthwise Electronic vial in the centre by operating the Leveling screw of one remainder.
  (Figure B)
- ⑤ The procedures are different according to the state of the Automatic inclination correction as following.



# [When using the Automatic inclination correction by 2 axes]

Please read procedure 6 because the horizontal angle and the perpendicular angle error by a perpendicular axis are automatically corrected.

# [When using the Automatic inclination correction by 1 axis]

The instrument is horizontally rotated by 180° after the bubble of the Electronic vial is adjusted on the centre at a left circle position side and confirm that the bubble of the vial is at the centre at the right circle position.

# [When using without Automatic inclination correction]

Confirm the bubble is at the centre even if the instrument is rotated by any 90°.


⑥ Confirm whether the plummet is on the ground mark. When you confirm it is not on the mark, loosen the centre screw and move the instrument over the ground mark correctly and fix the instrument by a centre screw. Repeat from ① to ⑥

# 3.5 Eyepiece adjustment

# [Eyepiece adjustment]

The eyepiece adjustment is performed before target sighting.


- ① Remove the telescope lens cap.
- ② Point the telescope at a bright object, and rotate the eyepiece ring full counter clockwise.
- 3 Look through the eyepiece, and rotate the eyepiece ring clockwise until the reticle appears at its maximum sharpness.
- When looking into the eyepiece, avoid an intense look to prevent parallax and eye fatigue.
- When it is hard to see the reticle due to poor brightness, press [ILLU] + [F3][RETICLE] to access the RETICLE INTENSITY ADJ. screen. Use the left and right arrow to adjust the reticle intensity.



# 3.6 Target sighting

# [Target sighting by Manual focus]

- ① Loosen the telescope clamp and horizontal clamp screws.
- ② Point the telescope at the target using a collimator.
- ③ Tighten the above two screws.
- 4 Adjust the eyepiece.
- ⑤ Look through the telescope and then rotate the Focus ring and stop it where the target can be clearly seen and the target image does not move in relation to reticle even if your eye is vertically and horizontally moved.
- 6 Align the reticle accurately on the target using telescope and horizontal tangent screws.



• The Focus ring rotation "clockwise" makes it possible to focus on closer objects and "counter clockwise" will focus on further objects.

#### 3.7 Attachment and detachment of tribrach

The tribrach of R-2501N, R-2502N, R-2503N, and R-2505N can be detached from the instrument, if required when replacing the instrument with a prism for example.

# [Detachment]


First loosen the recessed screw with a screwdriver, then rotate the locking knob until the arrow points upward, and lift the instrument up.

# [Attachment]

Mount the instrument on the tribrach with the guide marks coinciding, and rotate the locking knob until the arrow points downwards.

The guide and guide mark must be fitted to attach the instrument.

When the tribrach does not need to be attached or detached, or the instrument is to be transported, tighten the recessed screw with a screwdriver to fix the locking knob.



# 4. TURNING THE POWER ON

# 4.1 Turning the power on and off


To set power on: **①** To shut down: **①** 

To turn the power supply off, press the I/O key for more than 1 second and then release it. Power turns OFF.


**NOTE:** The power is automatically turned off after 10 minutes of inactivity (Factory default setting).

# 4.2 Adjusting LCD contrast


Press [F4] while holding down the Illumination key to access the screen for adjusting LCD contrast.



Pressing the [F1][ ← ] will lighten the contrast, while pressing the [F2][ ⇒ ] will darken the contrast.




Press [ENT] to exit adjustment mode and return to the previous screen.




- Pressing the Illumination key views the [F3][RETICLE], [F4][LCD] and [F5][ILLU].
- LCD contrast may be adjusted as necessary at any time.
- The contrast may be adjusted to any one of 25 levels.
- LCD contrast may be unappealing under certain environmental conditions such as high temperature. Adjust the LCD contrast as described above in such situations.

# 4.3 Adjusting illumination brightness


Press [F5] while holding down the Illumination key to access the screen for adjusting illumination brightness.



Pressing the [F1][  $\Leftrightarrow$  ] will decrease brightness, while pressing the [F2][  $\Rightarrow$  ] will increase brightness.



Press [ENT] to exit adjustment mode and return to the previous screen.



- Pressing the Illumination key views the [F3][RETICLE], [F4][LCD] and [F5][ILLU].
- Illumination brightness of the LCD screen and telescope reticle may be adjusted as necessary at any time.
- Illumination brightness may be adjusted to any one of 10 levels.

# 4.4 Adjusting reticle illumination


Press [F3] while holding down the Illumination key to access the screen for adjusting reticle illumination. The procedure to adjust the reticle illumination is the same way as 4.3.

• Pressing the Illumination key views the [F3][RETICLE], [F4][LCD] and [F5][ILLU].


# 5. ANGLE MEASUREMENT

#### 5.1 Measuring an angle


Aim at the first target, then press [F3][0 SET] twice in succession to reset the horizontal angle to 0.



Aim at the second target, then read the horizontal angle.




Pressing [F4][DISP] displays the vertical angle.



- The [F3][0 SET] key cannot reset the vertical angle to 0.
- Pressing the [F4][DISP] key cycles through the sets of display items: "H.angle/H.dst./V.dst.", "H.angle/V.angle/S.dst.", and
  - "H.angle/V.angle/H.dst./S.dst./V.dst.".
- Even though you turn the power off during a survey, the horizontal angle displayed last time is saved, so that it is restored when the power is turned on next time.
- When the restored horizontal angle is not necessary, reset it to 0.

# 5.2 Resetting the horizontal angle to 0


Pressing [F3][0 SET] twice in succession resets the horizontal angle to 0° 0' 0".



- The [F3][0 SET] cannot reset the vertical angle to 0.
- Pressing the [F3][0 SET] accidentally during measurement does not reset the horizontal angle to 0 unless you press it again. Once the buzzer stops sounding, you can go to the next step.
- You can reset the horizontal angle to 0 any time except when it has been held.

# 5.3 Holding the horizontal angle


To hold the horizontal angle currently being displayed, press [F3][HOLD] twice in succession. The horizontal angle value is displayed in reverse video when being held.




- If you want to hold the horizontal angle when you are in MODE A, press [F5][MODE] first to switch to MODE B, then press [F3][HOLD].
- The [F3][HOLD] cannot hold the vertical angle or distance.
- To release the horizontal angle from being held, press [F3][HOLD] once.
- Pressing [F3][HOLD] accidentally during measurement does not hold the horizontal angle unless you press it again. Once the buzzer stops sounding you can go to the next step.

## 5.4 Inputting an arbitrary horizontal angle


In case of Horizontal angle 123° 45' 20" input. Press [F5][MODE] to enter MODE B.




Press [F2][ANG SET] to display the ANGLE SET screen, then press [F4][ ♣ ] to move the cursor to "2. H.ANGLE INPUT".




Press [F5][SELECT] to open the horizontal angle input window.



[F5][CLEAR] is used to clear the values.




Press the numeric key as 123.4520.




Press the [ENT] key to accept the horizontal angle set to 123° 45' 20" and change the screen to MODE A.

• The former data is called by pressing the [CLEAR] key again.




# 5.5 Displaying the slope % of the vertical angle


Press [F5][MODE] to enter MODE B.




Press [F2][ANG SET] to display the ANGLE SET screen.



Press the [F5][SELECT] to change the screen to display the slope % of Vertical angle.



Press [F4][DISP] to display the slope value in %.




• The 0% represents the horizontal 0, and +100% and -100% represent 45° up and down slopes respectively.


- To return the screen from the slope (%) display to the 360° scale, also take above same steps by entering MODE B.
- If the slope (%) exceeds [+/-] 1000%, "Out of grade range" is displayed, indicating that the current vertical angle cannot be measured.
- When the telescope returns to a slope within slope [+/-] 1000%, the slope (%) display returns automatically from the "Out of grade range" message to the numeric value.

# 5.6 Changing the horizontal angle from clockwise to counter clockwise


Press [F5][MODE] to enter MODE B.




Press [F2][ANG SET] to display the ANGLE SET screen.



Press [F4][ ♣ ] to move the cursor to "3. R/L REVERSE".



Press [F5][SELECT] to add a minus sign (-) to the horizontal angle value as a counter clockwise angle.




- To return the horizontal angle from counter clockwise to clockwise, also take the above same procedures, press [F5][SELECT] to select the clockwise angle.
- When the counter clockwise horizontal angle is selected, the order of aiming at the targets becomes the reverse (the right one first, then the left one) of the order for the clockwise angle.

#### 6. DISTANCE MEASUREMENT

# **6.1 Target setting**

The target mode and its Constant of current setting are shown at the left of the battery mark. For example in case of each Constant 0, Reflectorless (Non-Prism); N 0, Prism; P 0



Pressing [F2][TARGET] changes the target mode.

- The target mode is changed sequentially as follows. Reflector sheet - Prism - Reflectorless
- The selected target mode is stored in the memory even if the power is turned off. So, next time you can use the same mode after turning on.
- The target Constant differs according to the selected target mode. So, confirm the target mode and its Constant shown at the top screen after changing the target.

# [Distance measurement by reflectorless (Non-Prism) mode]

- The measurement range and accuracy of Reflectorless are based on the condition that laser beam is emitted perpendicular to the white side of the Kodak Gray Card. The measurement range may be influenced by the shape of the target and its environment. There is a possibility that the range may vary when the target does not satisfy the conditions above at survey work.
- Pay attention to the following in case of distance measurement by Reflectorless. In case of resulting in low accuracy, perform the distance measurement by Prism.
- The CODE number 521 [LONG RANGE MES.] shows ON/OFF.
- The WARNING (Laser Power) screen is displayed when Message ON is selected, and then [F1][MEAS] key is pressed.
- Pressing [F1][MEAS] one time selects "Second MEAS setting" and twice selects "QUIT".
- ① There is a possibility that correct distance measurement may be impossible by dispersion or reduction of laser beam when the laser beam comes into the target from diagonal angle.
- ② There is a possibility that the instrument cannot calculate correctly when receiving reflected laser beam from forth and back directions in case of measuring the target on the road.
- ③ There is a possibility that synthesized values are calculated and the distance may become longer or shorter than the actual one when the operator measures the target of slope or sphere or rugged shape.
- ④ There is a possibility that the instrument cannot calculate correctly collecting the reflected laser beam from a man or a car that comes and goes in front of the target.

# [Distance measurement by reflector sheet mode]

Position the Reflector sheet whose reflecting surface faces the aiming line to be approx. right angle when the distance is measured by it. If it is positioned not to be approx. right angle, there is a possibility that correct distance measurement may be impossible by dispersion or reduction of laser beam.

#### [Applied measurement range by each target mode]

- When a wrong target mode is selected, a correct distance cannot be measured. Please select a correct target mode and measure.
- It is sometimes possible to measure without prism under special conditions like in the close distance, targeting on a wall surface. However, there is a possibility including some errors in this case, so be sure to select the reflectorless mode.
- The target constant should be correctly selected and confirmed in case that the reflector sheet is used at the prism mode and the prism is used at the reflector sheet mode.

#### **6.2 Distance measurement**


The R-2500N series has two distance measurement modes of primary MEAS and second MEAS. Pressing the [F1][MEAS] one time goes to primary MEAS and twice goes to second MEAS.

You can freely select and allocate your desired measurement mode in primary MEAS and second MEAS by the initial setting 2. The "MEASURE SHOT" is set at primary MEAS and "TRACK CONT" is set at second MEAS as a factory default setting.

- MEASURE SHOT means the distance measurement by the shot mode.
- MEASURE CONT means the distance measurement by the continuous mode.
- TRACK SHOT means the fast distance measurement by the shot mode.
- TRACK CONT means the fast distance measurement by the continuous mode. Confirm the target constant before beginning the distance measurement.

# **Example: "MEASURE SHOT" at primary MEAS (Factory default setting)**


Collimate the telescope at a target and press the [F1][MEAS] once to start measuring the distance. Once distance measurement has been started, the distance measurement mark remains displayed. Upon reception of a reflected light from the target, the instrument beeps and displays the mark to start the shot measurement automatically.



- If the instrument is in MODE B, press the [F5][MODE] to switch to MODE A and press [F1][MEAS].
- Pressing the [F1][MEAS] after collimating the telescope at the prism starts shot distance
  measurement with the "MEAS" text blinking. Distance measurement is completed and the
  "MEAS" text stops blinking the moment the distance measured by shot measurement is
  displayed. During continuous measurement, the "MEAS" text keeps on blinking. Pressing
  the [F1][MEAS] again terminates both distance measurement and blinking of the "MEAS"
  text.
- Pressing [F4][DISP] cycles through the sets of display items: "H.angle/H.dst./V.dst.", "H.angle/V.angle/S.dst.", and "H.angle/V.angle/H.dst./S.dst./V.dst."
- Pressing the [ESC] or [F2][TARGET] or [F5][MODE] during distance measurement stops it.
- If the shot count for distance measurement has been set to 2 or more in "initial setting 2", the distance is measured for the specified number of times to display the averaged value.

### **Example: "TRACK CONT" at second MEAS (Factory default setting)**

Collimate the telescope at a Target and press [F1][MEAS] twice to start measuring the distance. Upon reception of a reflected light from the target, the instrument beeps and displays the mark to start the TRACK distance measurement.




- If the instrument is in MODE B, press [F5][MODE] to switch to MODE A and press [F1][MEAS] twice.
- Pressing [F1][MEAS] twice after collimating the telescope at the Target starts Continuous distance measurement at fast speed with the "MEAS" text blinking.

  It remains blinking during the measurement. If you press the [F1][MEAS] again, Distance measurement is completed and the "MEAS" text stops blinking.
- Pressing [F4][DISP] cycles through the sets of display items: "H.angle/H.dst./V.dst.", "H.angle/V.angle/S.dst.", and "H.angle/V.angle/H.dst./S.dst./V.dst."
- Pressing the [ESC] or [F2][TARGET] or [F5][MODE] during fast distance measurement stops it.

#### 6.3 Quick mode

The Quick Mode is to shorten the measuring time using prism or reflector sheet.



- The Quick Mode is effective to measure the distance up to 500M using prism or reflector sheet
- After selecting Quick Mode from the Quick Mode setting screen, the distance measurement is done in Quick Mode.
- If the Quick Mode is selected, the distance measurement mark, "<-<- ->->", instead of "((( )))", is displayed

## 7. CORRECTION MODE

#### 7.1 Changing the target constant

Changing the Target Constant can be performed only when the Reflector sheet and Prism Constant setting are "INPUT" in initial setting 1.


Example: Prism Constant -25mm setting


Press [F4][CORR] in MODE B. (If the instrument is in MODE A, press [F5][MODE] to enter MODE B.)


Press the [F5][SELECT] to enable the Prism Constant to be changed.


Clear the exiting values by pressing [F5][CLEAR]. Input -25 by pressing the numeric keys.


Press the [ENT] key to accept the Prism Constant to -25mm.











- To set the Reflector sheet constant to "0mm" select "0mm" for "SHEET CONST" in "initial setting 1".
- To set the Prism constant to "0mm" or "-30mm" select "0mm" for "PRISM CONST" in "initial setting 1".
- When the "Sheet Constant" has been set to "0mm" in "initial setting 1" and "PRISM CONST" has been set to "0mm" or "-30mm", "\*" is displayed to the left of "0mm" or "30mm" on the correction menu screen. When "\*" is on the screen, the Constant cannot be changed (by entering a numeric key).
- Once set, the Reflector sheet Constant and Prism Constant remain on the measurement screen as "S 0" or "P 0".

- The factory initial of Reflector sheet Constant and Prism Constant are 0.
- Once set, each Constant remains in memory even after the power is turned off.

#### 7.2 Changing the temperature

The temperature setting can be changed only when "ATM CORR" has been set to "ATM INPUT" in "initial setting 1".

Example: Setting the temperature to +22°C

Press [F4][CORR] in MODE B. (If the instrument is in MODE A, press [F5][MODE] to enter MODE B.)

Press [F4][ ♣ ] to move the cursor to "3.TEMP" and press the [F5][SELECT] to enable the temperature to be changed.

TEMP

1. PRISM CONST \* -30mm
2. SHEET CONST \* 0mm
3. TEMP
: +15°C

0mm

0ppm

0ppm

CLEAR

1013hPa


CORRECTION

PRESS

ppm

PPM

Clear the exiting values by pressing [F5][CLEAR]. Input 22 by pressing the numeric keys.




Press the [ENT] key to accept the temperature to +22°C.

CORRECTION

1. PRISM CONST \* -30mm
2. SHEET CONST \* 0mm
3. TEMP : +22°C
4. PRESS : 1013hPa
5. ppm \* 0ppm

SELECT



- The valid range of Temperature input is from -30°C to +60°C.
- When "ATM CORR" in "initial setting 1" has been set to "4. NIL", "\*" is displayed to the left of the temperature value on the correction menu screen. When "\*" is on the screen, the temperature cannot be changed. If "ATM CORR" in "initial setting 1" has been set to "3. ppm INPUT", no temperature is displayed on the correction menu screen.
- Once set, the temperature is displayed at the centre of the top of the measurement screen.
- The factory initial of temperature is "+15°F".
- Once set, the temperature remains in memory even after the power is turned off.

Temperature correction is based on 15°C.
 If this instrument is used without correcting the temperature, a distance error per 100m is about -0.1mm per +1°C as a temperature difference from 15°C.
 A distance error per 100m is about 0.1mm per -1°C as a temperature difference from 15°C.
 (For more accurate values, See "12.4 Error when no atmospheric correction is made".)

#### 7.3 Changing the atmospheric pressure

The atmospheric pressure setting can be changed only when "ATM CORR" has been set to "ATM INPUT" in "initial setting 1".


Example: Setting the pressure to 900hPa


Press [F4][CORR] in MODE B. (If the instrument is in MODE A, press [F5][MODE] to enter MODE B.)


Press [F4][ ♣ ] to move the cursor to "4.PRESS" and press the [F5][SELECT] to enable the temperature to be changed.


Clear the exiting values by pressing [F5][CLEAR]. Input 900 by pressing the numeric keys.


Press the [ENT] key to accept the PRESS to 900hPa.











- The valid range of Pressure input is from 600 to 1120hPa (420 840mmHg).
- When "Atmospheric Correction" in "initial setting 1" has been set to "4. NIL", "\*" is displayed to the left of the pressure value on the correction menu screen.
   When "\*" is on the screen, the pressure cannot be changed.
   If "ATM CORR" in "initial setting 1" has been set to "3.ppm INPUT", no pressure is displayed on the correction menu screen.

- Once set, the pressure is displayed at the centre of the top of the measurement screen.
- The factory initial of pressure is "1013hPa".
- Once set, the pressure remains in memory even after the power is turned off.
- Pressure correction is based on 1013 hectopascals (hPa).
- If this instrument is used without correcting the pressure, a distance error per 100m is about -0.3mm per -10hPa as a pressure difference from 1013hPa.


(For more accurate values, see "12.4 Error when no atmospheric correction is made".)


### 7.4 Changing the ppm value

The ppm value can be changed only when "ATM CORR" has been set to "ppm INPUT" in "initial setting 1". "TEMP" and "PRESS" are not displayed.


Example: Setting the ppm value to 31 ppm.

Press [F4][CORR] in MODE B.







Clear the exiting values by pressing [F5][CLEAR]. Input 31 by pressing the numeric keys.



Press the [ENT] key to accept the PPM to 31ppm.





- The valid range of ppm values is from -199 to +199.
- Once set, the ppm value is displayed at the centre of the top of the measurement screen.
- The factory initial of ppm value is "1. AUTO".
- Once set, the ppm value remains in memory even after the power is turned off.

#### 8. INITIAL SETTING

#### 8.1 Overview

For the R-2500N series, you can select and save the desired setting for a variety of prescribed instrument conditions, called initial setting.

The Initial Setting is saved in six modes, "initial setting 1", "initial setting 2",


"initial setting 3", "initial setting 4", and "initial setting 5" in which you can select and save the instrument conditions described below.

The factory default for each of these conditions is marked by


To change initial setting, follow the operating procedures for entering each initial setting mode in "8.2" and the operating procedures for changing an initial setting in "8.2".

#### 8.2 Entering the mode for initial setting 1

Press the [POWER] key while holding [F1] key down to access the screen for initial setting 1.




- Pressing [F1][ △] scrolls it up five items;
   pressing [F2][ ▽] scrolls the screen down five items.
- Press [F3][ ☆ ] or [F4][ ⇩ ] to position the cursor at the item of interest.



### 8.3 Entering the mode for initial setting 2

Press the [POWER] key while holding [F2] key down to access the screen for initial setting 2.

• Select the item of interest in the same way as in the mode for initial setting 2.



#### 8.4 Entering the mode for initial setting 4

Press the [POWER] key while holding [F4] key down to access the screen for initial setting 4.


• Select the item of interest in the same way as in the mode for initial setting 4.



## 8.5 Entering the mode for initial setting 5

Press the [POWER] key while holding [F5] key down to access the screen for initial setting 5.

• Select the item of interest in the same way as in the mode for initial setting 5.



## 8.6 Entering the mode for setting of date and time


Press the [POWER] key while holding [F3]+[F4] key down to access the screen for Date · Time Input.




# 8.7 Example of changing an initial setting content (selection of atmospheric correction)

This section describes the operating procedures for selecting "1.ATM CORR" in initial setting 1 as an example of changing an initial setting content. Use this example as a reference when changing other items because it is also applicable to the operating procedures for changing them.

Access the screen for initial setting 1 by taking procedures "8.2 Enter the mode for initial setting 1".




Press [F5][SELECT] to open the screen for selecting the atmospheric correction.




Press [F3][ 1] or [F4][ 1] to position the cursor at the desired item, then press [ENT] key to select that item.

Pressing the [ENT] key selects the change of selected item. Pressing the [ESC] key invalidates the



change of selected item.

Pressing again the [ESC] key or [ENT] key quits the initial setting screen and usual start screen appears.



#### 8.8 Initial setting 1

- 1. Selection of **Atmospheric Correction**: [ATM CORR]
  Select whether Atmospheric Correction is to be performed by using the automatic measurement correction function with an atmospheric sensor, by entering the atmospheric temperature and pressure measured with a thermometer and barometer, by entering ppm value, or by fixing the ppm value to 0 (NIL) not to perform Atmospheric Correction.
- 1. AUTO 2. ATM INPUT 3. ppm INPUT 4. NIL
- 2. Selection of **Prism Constant**: [PRISM CONST.] Select whether the Prism Constant to be input is set to 0mm, -30mm or to an arbitrary value to be entered from the keyboard.
- 1. -30mm 2. Omm 3. INPUT
- 3. Selection for **Reflector sheet Constant**: [SHEET CONST]
  Select whether the target constant to be input is set to 0mm, or to an arbitrary value to be entered from the keyboard.
- 1. Omm 2. INPUT
- 4. Selection for **Refraction & Curvature Corrections**: [CRV/REF CORR]
  Select whether the correction factor to be input for both differences (Refraction, Curvature) is set to 0.14, 0.2 or none (NIL). Selecting "3. NIL" results in no correction of both values.
- 1. 0. 14 2. 0. 2 3. NIL
- 5. Selection of **Tilt Compensation**: [COMP AXIS] Select whether Tilt Compensation is to be single-axis compensation, dual-axis compensation, triple-axis compensation, or disabled (NIL).
- 1. 3 AXIS
  2. 2 AXIS
  3. 1 AXIS
  4. NIL

  1. 2 AXIS
  2. 1 AXIS
  3. NIL

ullet The factory default for each instrument condition is marked by  $\hfill \Box$ .


Measurement Systems Ltd.

#### 8.9 Initial setting 2

 Selection of the Minimum Distance measurement unit and Quick Mode: [EDM MIN DISP/QUICK] More fine angle view is necessary, select 0.1mm, Besides that, select 1mm/OFF.
 When using Quick Mode, select 1mm/ON.



2. Selection of the **Shot count**: [SHOT COUNT] Select whether the shot count for Shot distance measurement is to be 1, 3, 5 or an arbitrary count to be entered.




3. Setting the **Shot input**: [SHOT INPUT] Set the shot number for Shot distance measurement.



- The valid range of values for the shot number is from 1 to 99.
- This setting is enabled only when the shot number (Above 2.) has been set to "4. INPUT".
- 4. Selection of **Laser plummet**: [LD PLUM.] Laser plumb ON/OFF is selected.




5. Selection of **Tilting angle display**: [TILT DISP.] X and Y tilting values are displayed.



6. Selection of **Minimum tilt display**: [TILT DISP UNIT] COARSE or FINE.



7. Selection of **Long range message** : [LONG RANGE MES.]
If you need the long range message.



8. Selection of **primary MEAS setting**: [PRIM. MEAS KEY]
Select whether the primary distance measurement is
MEAS SHOT or MEAS CONT or TRACK SHOT or
TRACK CONT.



9. Selection of **second MEAS setting**: [SEC. MEAS KEY] Select whether the second distance measurement is TRACK CONT or TRACK SHOT or MEAS CONT or MEAS SHOT.

1. TRACK CONT 2. TRACK SHOT 3. MEAS. CONT 4. MEAS. SHOT

10. Selection of **Minimum angle display**: [MIN UNIT ANG.] Select whether to set the minimum angle display mode to "COARSE (5 seconds)" or "FINE (1 second)".

1. COARSE 2. FINE

11. Selection of **Vertical angle style**: [V.ANG. STYLE] Select whether the 0 point for vertical angle is set to be "Z.0", "H.0" or "COMPAS".

1. Z. O 2. H. O 3. COMPAS

12. Selection of **Automatic power-off function** : [AUTO OFF]

Select the time interval (10, 20 or 30 minutes) for activating the automatic power-off function, or select NIL, disabling the function.

1. 10 MIN 2. 20 MIN 3. 30 MIN 4. NIL

- The automatic power-off function automatically turns the power supply off after the specified period of time (in minutes) when no operation for distance measurement or for key entry has been performed with the angle remaining unchanged.
- 13. Selection of **Distance measurement automatic power-off function**: [EDM OFF]

Select the time interval (3, 5, or 10 minutes) for activating the distance measurement automatic power-off function, or select NIL, disabling the function.

1. 3 MIN 2. 5 MIN 3.10 MIN 4.NIL

14. Selection of **Automatic illumination power-off function**: [ILLU. OFF]

Select the time interval (3, 5, or 10 minutes) for activating the automatic illumination power-off function, or select NIL, disabling the function.

1. 3 MIN 2. 5 MIN 3.10 MIN 4.NIL

15. Selection of **Distance measurement buzzer** 

: [DIST. BUZ]

Select whether to enable or disable the beep when the prism receives a light during distance measurement or during repeated distance measurement.

1. ON 2. OFF 16. Selection for **H.angle 90° buzzer**: [QUAD. BUZ] Select whether to enable or disable the beep at every 90° during angle measurement.

1. OFF 2. ON

17. Selection of **Distance measurement signal** : [MEAS. SIGNAL]

Select whether to display a signal indicator or AIM value to be displayed from when distance measurement is started to when measured data is displayed.

1. MARK 2. VALUE

18. Selection of Priority Display: [PRIORITY DISP.]
Select the display order of the sets of display items which pressing the [DISP] key cycles through. The set of display items selected here appears first after the power is turned on.

1. HA VA VD 2. HA VA SD 3. HAVA HDSDVD

#### 8.10 Initial setting 4

1. Selection of **Temperature unit setting**: [TEMP. UNIT] Select °C or °F as the unit for Temperature.

1. ° C 2. ° F

2. Selection of **Pressure unit setting**: [PRESS UNIT] Select hPa (hectopascal), mmHg, inchHg as the unit for pressure to be input.

1. hPa 2. mmHG 3. inchHG

3. Selection of **Distance unit setting**: [DIST. UNIT] Select m or ft or ft+inch as the unit for Distance.

1.m 2.ft 3.ft+inch

4. Selection of **Angle unit setting**: [ANG. UNIT] Select DEG or DEC or GRD or MIL as the unit for Angle.

1. DEG 2. DEC 3. GRD 4. MIL

## 8.11 Initial setting 5

Selection of Communication Setting: [COMM.SELECT] Select RS-232C or Bluetooth.

1. RS-2320 2. Bluetooth

#### You have to perform the following setup, when you choose "RS-232C."

1. Selection of **Transfer rate** (baud rate): [BAUD UNIT] Select a baud rate of 1200, 2400, 4800 or 9600.

1. 1200	
2. 2400	
3. 4800	
4. 9600	


2. Selection of **Data bits**: [DATA LENGTH] Select a data length of 8 bits.



3. Selection of **Parity**: [PARITY BITS] Select no (NIL) parity bit, even parity or odd parity.




4. Selection of **Stop bits**: [STOP BITS] Select the number of stop bits to be used: 1 or 2.




5. Selection of **Control signal**: [SIGNAL CONTROL] Select whether the control signal is effective or not.



6. Selection of **XON/XOFF**: [XON/XOFF] Select whether to enable or disable XON/XOFF.



7. Selection of **Through command**: [THROUGH COMMAND]
Select whether to disable data output
without receiving any data request command
or enable the "a" to "f" command data output.



## 8.14 Setting of date and time


Input of date
 Set date using [numeric keys].
 Year / month / date

**0**8/12/24

2. Input of time
Set time using [numeric keys].
Time: minute: second

**0**0:00:01

3. Selection of week day Select week day.



• The date clock is powered by the built-in lithium battery. The lithium battery needs to be replaced in five years. When the message "Li-batt.voltage s low." is shown on the display screen, have the lithium battery replaced by the dealer from whom the instrument was purchased. The timing of battery replacement varies depending on the frequency of use and the environment where the instrument is stored while not in use.



## 9. ACCESSING THE FUNCTIONS

## 9.1 Accessing by help key

You can use the [HELP] key to display specific initial setting (such as the prism constant and priority mode).

Press the [ILLU]+[ESC] key in MODE A or B.




The help menu will then be displayed. Press [F1][  $\triangle$  ][F2][  $\nabla$  ] or [F3][  $\diamondsuit$  ][F4][  $\diamondsuit$  ] to position the cursor to the desired item.


#### 9.2 Accessing by 007

The R-2500N allows you to enter a special code of 007 with the alphanumeric keys to display specific initial setting.


Press the numeric keys [0][0][7] in MODE A or B. The screen will then change to the command input screen.



Press the numeric keys for the desired command number in the Command No. Table. (For example, press [4][0][1] for TARGET CONST.)



Press the [ENT] key to access the TARGET CONST.



## [Instrument setting items]

007	HELP menu list		Default	Other options	
401	TARGET CONST	PRISM CONST	-30mm	0mm, INPUT	
		SHEET CONST	0mm	INPUT	
402	ATM CORR		AUTO	ATM INPUT,	
			※R−2501N, R−2502N	ppm INPUT,	
			ATM INPUT,	NIL	
			<b>※</b> R−2503N, R−2505N		
501	EDM MIN DISP/QUICK		1mm/OFF	1mm/ON, 0.1mm	
502	SHOT COUNT	SHOT COUNT	1TIME	3TIMES, 5TIMES, INPUT	
		SHOT INPUT	01TIMES	(input)	
503	CRV/REF CORR.		0.14	0.2, NIL	
504	MIN UNIT ANG.		FINE	COARSE	
505	V.ANG. STYLE		Z.0	H.0, COMPAS	
508	DIST. BUZ.		ON	OFF	
509	QUAD BUZ.		OFF 🛕	ON	
510	AUTO OFF		10 MIN	20 MIN, 30 MIN, NIL	
511	EDM OFF		3 MIN	5 MIN, 10 MIN, NIL	
512	ILL. OFF		3 MIN	5 MIN, 10 MIN, NIL	
514	MEAS. SIGNAL		MARK	VALUE	
515	PRIORITY SELECT	PRIM. MEAS KEY	MEAS. SHOT	MEAS. CONT, TRACK	
			× 2 3	SHOT, TRACK CONT	
		SEC. MEAS KEY	TRACK CONT	TRACK SHOT, MEAS.	
		SES. INEXTO RET	1101011 00111	CONT, MEAS. SHOT	
		PRIORITY DISP.	HA/HD/VD	HA/VA/SD,	
			1170/1187 48	HA/VA/HD/SD/VD	
517	COMP AXIS	Meas	3 AXIS	2 AXIS	
•			XR-2501N, R-2502N	1 AXIS,	
			2 AXIS	NIL NIL	
			%R-2503N, R-2505N		
520	LD PLUM. & E.VIAL	LD PLUM.	OFF	ON	
		TILT DISP	OFF	ON	
		TILT DISP UNIT	COARSE	FINE	
521	LONG RANGE MES.	<b></b>	ON	OFF	
523	ATM CORR DISP	※ R-2503N,R-2505N only	OFF	ON	
701	ATM UNIT	TEMP. UNIT	° C	°F	
		PRESS UNIT	hPa	mmHg, inchHg	
702	DIST. UNIT		m	ft, ft+inch	
703	ANG. UNIT		DEG	DEC, GRD, MIL	
801	SETUP COM.	BAUD RATE	1200	2400, 4800, 9600	
		DATA LENGTH	8		
		PARITY BITS	NIL	EVEN, ODD	
		STOP BITS	1	2	
		SIGNAL CONTROL	ON	OFF	
		XON / XOFF	ON	OFF	
		THROUGH COMMAND	NIL	a, b, c, d, e, f	
	OOMM CELEOT	1	RS-232C	Bluetooth	
802	COMM.SELECT		I NO ZUZU		

#### 10. DATA COLLECTOR

The instrument can communicate directly with a computer through the RS-232c interface. By use of a data collector you can automate data entry, from the collection of survey data to the transfer of the data to a computer. This is useful in saving time and protecting data integrity. For instructions about the connection with a data collector and the handling, please refer to the "Instruction manual" of the data collector.

### 11. CHECKS AND ADJUSTMENTS

- Checks and adjustments should be performed before and during measurement.
- The instrument should be checked after long storage and transportation.
- The checks should be performed in the following order.


#### [Cautions on CHECKS AND ADJUSTMENTS]

- When adjustment is completed, be sure that adjusting screws are completely tightened. When finishing turning adjusting screws, be sure that screws are turned in a direction for tightening.
- Repeat check after adjustment, and check if the instrument has been adjusted properly.
- When adjustment is completed, be sure that adjusting screws are completely tightened.
   When finishing turning adjusting screws, be sure that screws are turned in a direction for tightening.
- Repeat check after adjustment, and check if the instrument has been adjusted properly.

#### 11.1 Plate level

#### [Checks]

- ① Align the Plate level in parallel with a line joining any two of the levelling screws. Then, adjust the two screws to centre the bubble in the vial.
- ② Turn two leveling screws in an opposite direction mutually and move the bubble of the side of the electronic vial to the centre.
- ③ Move the bubble over the length of the electronic vial to the centre by operating the leveling screw of one remainder.
- Rotate the instrument by 180° and confirm the position of the bubble of the electronic vial.
   At this time, it is not necessary to adjust it if the bubble of the electronic vial is in the vicinity of the centre.



- Please check the electronic vial in a steady environment that has no vibration or rapid temperature change.
- When the electronic vial is checked outdoors and on a tripod, avoid sunlight influence by using a sunshade. Please wait for a while until the instrument and tripod are at the same temperature as the surrounding air.
- When the instrument is seen at the position of "Left circle", movement and the inclination of the instrument become the same on the screen in the electronic vial. Please note that the movement of the bubble becomes opposite direction if it is seen at the position of "Right circle".

#### [Adjustments]

It is necessary to adjust as following when the bubble is not in the vicinity of the centre in the confirmation of ④.

#### [Procedure to adjust the electronic vial]


Press the [POWER] and [LASER] key simultaneously.



Aim at a target and press [F3][0 SET].



Turn the instrument 180° and reverse the telescope. Aim at the same target accurately, then press [F3][0 SET].



Pressing the [ENT] key completes the adjustment.

#### 11.2 Circular vial

#### [Checks]

- ① Adjust by the plate level vial beforehand.
- ② Confirm the position of the bubble of the circular vial.

  At this time, it is not necessary to adjust if the bubble is at the centre of the circle.

#### [Adjustments]


When the bubble of the circular vial comes off from the centre according to check procedure ②, it is necessary to adjust.

Turn the bubble adjustment screws with the reticle adjustment pin and put the bubble in the centre of the circle.

#### [Only the detaching type model]

Turn the bubble adjustment screws with the reticle adjustment pin and put the bubble in the centre of the circle.


• Tighten the screws equally after the above adjustment.



#### 11.3 Vertical reticle


#### [Checks]

- ① Set the instrument up the tripod and carefully level it.
- ② Sight the target Point A with telescope.
- ③ Using the telescope fine adjustment screws, move Point A to the edge of the field of view by screw (Point A').
- 4 No adjustment is necessary if Point A moves along the vertical line of the reticle.



#### [Adjustments]


- ① If Point A is off from the vertical line of the reticle, first remove the eyepiece cover.
- ② Using the adjusting pin, loosen the four reticle adjustment screws slightly by the same amount, then rotate the reticle line around the sight axis and align the vertical line of the sight axis with Point A'.
- ③ Tighten the reticle adjustment screws again by the same amount, and repeat the check to make sure the adjustment is correct.
- Since the R-2501N and R-2502N have triple axis compensation, it is necessary to make other settings besides the adjustments mentioned above. For details, contact the dealer from whom the instrument was purchased.



#### 11.4 Perpendicularity of line of sight to horizontal axis

#### [Checks]

- ① Position a target Point A at a distance 30m 50m away from the instrument, and sight it with the telescope.
- ② Loosen the telescope lock screw and turn the telescope until a point is sighted at a distance roughly equal to that of Point A. This is Point B.
- ③ With the telescope still reversed, loosen the horizontal lock screw and rotate the instrument around the vertical axis, and sight Point A again.
- 4 Loosen the telescope lock screw and turn the telescope until a point is sighted at a distance equal to that of Point B. This is Point C.
- ⑤ No adjustment is necessary if Point B and C are aligned.



#### [Adjustments]

- ① If Points B and C are not aligned, mark Point D at 1/4 the length of the BC, from Point C in the direction of Point B.
- ② Using the adjustment pin, rotate the reticle adjustment screws horizontally opposite each other (see preceding page), and move the reticle to sight Point D.
- ③ Repeat the check and make sure the adjustment is correct.
- Since the R-2501N and R-2502N have triple axis compensation, it is necessary to make other settings besides the adjustments mentioned above. For details, contact the dealer from whom the instrument was purchased.

#### 11.5 Vertical 0 point error

Make sure to follow check procedures mentioned below after making adjustments on reticle and perpendicularity of line of sight to horizontal axis.

#### [Checks]

- ① Set up the instrument and turn the power on.
- ② Sight the telescope at any reference target A at Normal state. Read the vertical angle (y).
- ③ Turn the telescope and rotate the alidade. Sight the same target A again at Back state and read the vertical angle R.

If  $y+R = 360^{\circ}$ , no further adjustment is necessary.


#### [Adjustments]

If the deviation d (y+ R - 360°) is wide, contact your local dealer.

#### 11.6 Laser plummet

#### [Checks]

- ① Set the instrument on the tripod, and place a piece of white paper with a cross drawn on it right under the instrument.
- ② Press the [LASER] key, and move the paper so that the intersecting point of the cross comes to the centre of the laser mark.
- 3 Rotate the instrument around the vertical axis, and observe the centre mark position against the intersecting point of the cross at each 90° rotation.
- 4 If the laser mark always coincides with the intersecting point, no adjustment is necessary.



#### [Adjustments]

When a centre part where a cross intersection and the laser mark look the brightest shifts by 0.5mm or more (at the instrument height 1.5m), it is necessary to adjust it.

A repair engineer does this adjustment. Please contact the PENTAX dealer.

#### 11.7 Offset constant

The offset constant rarely changes. It is recommended, however, that checks be done once or twice a year.

The check of the offset constant can be done on a certified base line. It can also be obtained in a simple way as described below.


#### [Checks]

- ① Locate points A, B and C at about 50m intervals on even ground.
- ② Set up the instrument at point A, and measure the distances between AB and AC.
- ③ Set up the instrument at point B, and measure the distance BC.
- 4 Obtain the offset constant (K):

K=AC - (AB+BC)

#### [Adjustments]

• Contact your local dealer for adjustment of the offset constant when K is not nearly 0.



## 11.8 Beam axis and line of sight

Be sure to check that the beam axis and line of sight are aligned when the adjustments on reticle and perpendicularity of line of sight to horizontal axis are made.

#### [Checks]

- ① Set the prism at a distance greater than 50m.
- ② Accurately sight the centre of the prism through the telescope.
- ③ Turn the power on and press (MEAS) to measure.
- ④ No adjustment is necessary if beam receiving buzzer sounds immediately and measurement value is displayed in a few seconds.

#### [Adjustments]

- If instrument function is not as described in ④, contact your local dealer.
- This check should be done under good weather conditions.


#### 11.9 The EDM beam axis

The distance measurement (EDM) beam axis is adjusted to be aligned to the sighting axis of the telescope, but it can be changed a little in case of rapid temperature change, shock or aging. Check your instrument by following procedures.

#### [Checks]

- ① Install the instrument on the tripod and level it at the distance of approx. 50m from the wall.
- ② Displace the target plate attached to the end of this manual. Place the target plate adjusting its centre to the centre of telescope cross line and to be about horizontal to the instrument.
- ③ Turn the power on, and confirm the [TARGET] is set to the reflector sheet mode ("S" will be indicated at the top of display, left side of the battery remains sign when it is that.)

  When it is not, press [F2][TARGET] and set to reflector sheet mode (refere to "6.1 Target setting").
- ④ Press [F1][MEAS], then the laser spot appears on the target plate. If the "Centre" of the laser spot is within the internal circle (10mm) of the target plate at this moment, the adjustment is unnecessary.
- The laser spot disappears in approx. 20 seconds after pressing [F1][MEAS]. Press [MEAS] again, if it is necessary.



[Example: Adjustment is necessary] [Example: Adjustment is unnecessary]

#### [Adjustments]

At the procedure 4. above, if the "Centre" of laser spot is not within the internal circle (10mm) of the target plate, the adjustment is necessary. Please contact your PENTAX dealer.

## 12. APPENDIX

## 12.1 Warning and Error Messages

Warning Message	Meaning	What to do
Out of tilt range	Displayed when the instrument is tilted beyond the vertical compensation range (±3') in case automatic compensation is selected.  When it is properly leveled, this message may be temporarily displayed if the instrument is turned too fast.	Re-level the instrument. Repair is needed if the message is displayed when it is properly levelled.
Excess data	The input data exceeds the allowable range.	Press the [ESC] key and enter the correct data.
Out of range (when being lit)	This message is displayed if a long distance which is far beyond measurable distance of R-2500N series is measured with a wrong target mode.  Please select a correct target then measure.  If a wrong target is selected, a correct distance cannot be measured.	Select the correct target mode.
Out of range (when flashing)	The measurement distance is less than 1.5m in Reflector sheet mode. The measurement distance is less than 5m in Prism mode.	Select a longer point, or use a tape measurer.
Unsuitable Condition	Under too strong sunlight. Unstable light value owing to shimmer or obstacles. Reflector sheet, Target and Prism do not face the instrument. Reflector sheet, Target and Prism are not correctly sighted. Measurement range is over in Reflectorless mode. Sufficient signal does not return by sighting sharp edge etc. at Reflectorless mode.	Change the object that has much better reflectivity or use a prism, or wait until the sun activity has weakened.
Li-batt.voltage is low.	<ul> <li>The Date Clock is powered by the built-in lithium battery.</li> <li>The lithium battery needs to be replaced in five years.</li> </ul>	Have the lithium battery replaced by the dealer from whom the instrument was purchased.

Error Message	Meaning	What to do		
EDM ERROR 04 -05, 34-39, 50-53	Distance measurement system problem	Turn the power off, and then turn on		
ETH ERROR 70-76	Angle measurement system problem	again.		
MEMORY ERROR 19	Memory problem	Repair is needed when the message		
ERROR PS DATA of EDM ERROR P DATA of EDM	Problem of the internal EDM parameters	appears consistently.		
ERROR ETH DATA	Problem of the internal ETH parameters	•		

#### 12.2 Atmospheric correction

The speed at which light travels through the air varies depending on the temperature and atmospheric pressure. The R-2500N series is designed to measure distances at the speed of light. In order to measure accurately, atmospheric correction needs to be used. The instrument is designed to correct for weather conditions automatically if the temperature and pressure are input. Correction is then carried out based on the following formula.

Calculation formula
$$K = (276.26713 - \frac{78.565271 \cdot P}{273.14941 + t}) \times 10^{-4}$$

K: Atmospheric Correction Constant

P: Atmospheric pressure (hPa)

t: Temperature(°C)

Distance after Atmospheric Correction D = Ds(1+K)

Ds: Measured distance when no Atmospheric Correction is used.

## 12.3 hPa and mmHg conversion table

### [Converting from hPa to mmHg]

#### Unit:mmHg

hPa	0	10	20	30	40	50	60	70	80	90
500	375	383	390	398	405	413	420	428	435	443
600	450	458	465	473	480	488	495	503	510	518
700	525	533	540	548	555	563	570	578	585	593
800	600	608	615	623	630	638	645	653	660	668
900	675	683	690	698	705	713	720	728	735	743
1000	750	758	765	773	780	788	795	803	810	818
1100	825	833	840	848	855	863	870	878	885	893
1200	900	908	915	923	930	938	945	953	960	968

#### [Converting from mmHg to hPa]

Unit:hPa

mmHg	0	10	20	30	40	50	60	70	80	90
400	533	547	560	573	587	600	613	627	640	653
500	667	680	693	707	720	733	747	760	773	787
600	800	813	827	840	853	867	880	893	907	920
700	933	947	960	973	987	1000	1013	1027	1040	1053
800	1067	1080	1093	1107	1120	1133	1147	1160	1173	1187
900	1200	1213	1227	1240	1253	1267	1280	1293	1307	1320

#### 12.4 Error when no atmospheric correction is made

When measurement is carried out with no atmospheric correction (with the settings fixed at a temperature of 15°C and an atmospheric pressure of 1013hPa or 760mmHg), the error per 100 meters in temperature and pressure will be shown in the tables below.

• When the actual pressure is 1013hPa (760mmHg) and the temperature is 25°C, conducting the measurement with the temperature left at 15°C will result in the measurement being short by 0.9mm per 100 meters.

#### [Error table: When hPa (15°C, 1013hPa as standard)]

Unit:mm

hPa C°	1200	1100	1013	900	800	700	600	500
45	2.0	-0.5	-2.6	<b>−</b> 5.5	-8.0	-10.5	-13.0	-15.5
35	3.0	0.4	-1.8	<b>-4.7</b>	-7.3	-9.9	-12.5	-15.1
25	4.0	1.4	-0.9	-4.0	-6.6	-9.3	-12.0	-14.6
15	5.2	2.4	-0.0	<b>−3.1</b>	-5.9	-8.6	-11.4	-14.2
5	6.3	3.5	1.0	-2.2	<b>−</b> 5.1	-8.0	-10.8	-13.7
-5	7.6	4.7	2.1	-1.3	-4.2	-7.2	-10.2	-13.1
-15	9.0	5.9	3.2	-0.2	-3.3	-6.4	-9.5	-12.6

## [Error table: With mmHg (15°C, 760mmHg as standard)]

Unit:mm

C° mmHg	900	800	760	700	600	500	400
45	2.0	-1.3	-2.6	-4.6	-8.0	-11.3	-14.6
35	3.0	-0.4	-1.8	-3.9	-7.3	-10.8	-14.2
25	4.0	0.5	-0.9	-3.1	-6.6	-10.2	-13.7
15	5.2	1.5	0.0	-2.2	-5.9	-9.6	-13.3
5	6.3	2.5	1.0	-1.3	<b>−</b> 5.1	-8.9	-12.7
<b>-</b> 5	7.6	3.7	2.1	-0.3	-4.2	-8.2	-12.2
-15	9.0	4.9	3.2	0.8	-3.3	-7.4	-11.5

#### 12.5 Atmospheric refraction and earth curvature correction

- Atmospheric refraction and earth curvature correction refers to correcting both the bending of the light beam caused by atmospheric refraction and the effect on the height differential and horizontal distance caused by the earth curvature.
- Correction called "atmospheric refraction and earth curvature correction" is initiated to correct error when the slope distance and vertical angle are caused to determine the horizontal distance and the height differential. With this instrument, the following formula is used to correct these factors.
- Calculation formula when atmospheric refraction and earth curvature correction parameter is set to "ON":

### **Corrected horizontal distance (H)**

$$H = S(\cos \alpha + \sin \alpha \cdot \frac{K-2}{2Re} \cdot S \cdot \cos \alpha)$$

#### **Corrected vertical distance (V)**

$$V = S (\sin \alpha + \cos \alpha - \cdots - S - \cos \alpha)$$

• Calculation formula when atmospheric refraction and earth curvature correction parameter is set to "OFF":


Horizontal distance 
$$H' = S \cdot \cos \alpha$$
  
Vertical distance  $V' = S \cdot \sin \alpha$ 

S: Slope distance

 $\alpha$ : Vertical angle from horizontal

K: Atmospheric refraction coefficient (0.14 or 0.2)

Re: Diameter of earth (6,370 km)



#### 12.6 Distance range

Generally speaking, the maximum range which can be measured varies considerably depending on the atmospheric conditions. For this reason, the specifications illustrate the values for both good and normal weather conditions.

It is extremely difficult to judge when weather conditions are "Good" and when they are "Normal". With this instrument, the conditions noted below are used to differentiate between the two situations (good weather conditions for surveying are different from normal weather conditions, and in surveying situations, cloudy skies are considered more favourable than sunny skies).

Weather conditions for measurement ranges are based on the following standard values:

Normal: Visibility of approximately 20 km, with slight shimmer and moderate wind.

aner al Maranta Argina III. A Maranta Argina Visibility of approximately 40 km, overcast, with no shimmer and moderate wind.

## **12.7 Specifications**

		R-2501N	R-2502N	R-2503N	R-2505N	
Telescope						
Magnification			30	x		
Effective aperture			45mm ( EDI	M45mm )		
Resolving power			3.0′	7		
Field of view			2.6% ( 1°	30')		
Minimum focus			1.0r	m		
Focus			Manu	ıal		
Distance measurement						
Laser Class		Visible Laser : 0	Class IIIa ( Reflector	rless)/ Class I	I ( Prism, sheet )	
Measurement range (Go	ood condition) *3	3				
Reflectorless *1			1.5 ~ 6	600m		
Reflector sheet *2			1.5 <b>~</b> 600r	m(800m)		
Mini prism			1.5 <b>~</b> 2500r	m(3000m)		
1P			1.5 ~ 7000r	m(9000m)		
3P		1.5 ~ 9000m(9999m)				
Accuracy *4			,53			
Prism / Reflector Sho	eet	1.5m ~ 10m : ±(3+2ppm x D)mm 10m ~ : ±(2+2ppm x D)mm				
Reflectorless		1.5m ~ 150m : ±(3+2ppm x D)mm 150m~ 300m : ±(5+2ppm x D)mm 300m ~ : ±(7+10ppm x D)mm				
At Auto-ATM. Correct	etion	200	·			
Prism / Reflector s	sheet	1.5m ~ 10m: ±(3 10m ~ : ±(3	3+10ppmxD)mm 2+10ppmxD)mm			
Reflectorless	2	1.5m ~300m:±(5 300m~ :±(7	i+10ppmxD)mm 7+18ppmxD)mm			
Minimum count		0.1mm (Fine	mode), 1mm (Norr	mal mode), 10	mm (Track mode)	
Measurement time *5						
Repeat meas.	Normal(1mm):	Prism ,	Ref.sheet 2.0sec.	Ref.less 2.0s	ec.	
	Quick(1mm):	Prism ,	Ref.sheet 1.2sec.	*6		
	Track(10mm) :	Prism ,	Ref.sheet 0.4sec.	Ref.less 0.4s	ec.	
Initial meas.	Normal(1mm) :	Prism ,	Ref.sheet 2.5sec.	Ref.less 2.4s	ec.	
	Quick(1mm):	Prism ,	Ref.sheet 1.7sec.	*6		
	Track(10mm) :	Prism	/ Ref.sheet 2.5sec.	Ref.less 2.5s	ec.	

	R-2501N	R-2502N	R-2503N	R-2505N
Angle measurement		1		
Measuring method		Absolute rot	ary encoder	
Detection method		Vertical / Horizon	tal angle : 2 sides	
Minimum count		1" / 5" s	electable	
Accuracy (ISO17123-3)	1"	2"	3″	5″
Compensator	3 ax	is <b>*7</b>	2 a	ıxis
Tangent Screw	2 S	Speed	1 Sr	peed
Sensitivity of vials				
Plate level (electronic)	20"/1div. (electronic)	1div.		
Circular level		8'/2	mm	
Plummet	Visible Laser,	±0.5mm (instrumer	t height 1.5m) or	Optical(Option)
Base		Detac	hable	
Dust and Water Protection		IP66 (instru	ıment only)	
Ambient temperature	-20° C	~ 50° C / -4° F	~ 122° F (Workin	ng range)
Tripod thread		5/8"	x 11	
Dimensions/Weight		che		
Dimensions		190(W) x 343(H	H) x 177(L)mm	
Weight (incl. Battery)	4	5.7	'kg	
Carrying case	ane	373(W) x 286(H) x	465(L)mm / 2.9k	
Battery pack BP07	200			
Power source	Lith	ium ION +6.2VDC	to 8.4VDC 2500i	mAH
Operation time	en (	Continuous approx. 15 hrs (ETH)		1),
Weight		210		
Battery charger BC05 and AC Adapter A	C05			
Input voltage (AC05)		AC 100	~240V	
Output voltage (BC05)		DC8	3.4V	
Data Process				
Data recording method		Internal	Memory	
Coordinates data <b>*8</b>		60000		50000
Special function		PowerT	opoLite	
I/F		RS-232C, SD CAF	RD, USB,Bluetooth	
Display / Keyboard	1			
Display type	Graphic	LCD / 20 character	s x 8 lines / 240 x	96 pixels
Quantity		2		1
Keys	22	each(12 numeric /	5 function / 5 spe	cial)
Display back light		Intensity sett		
Laser Pointer		Ye		
Date clock		Ye		

#### **NOTE:**

- \*1 The measurement range and accuracy of reflectorless, and time required to measure may vary by the shape, size of surface area and reflection rate of the target and its environment. The measurement range of reflectorless is determined by the white side of the Kodak Gray Card.
- \*2 Reflector sheet: PENTAX genuine Reflector sheet
- \*3 The measurement range may vary by conditions of the environment.

  Normal conditions: 20km visibility with slight shimmer Good conditions: 40km visibility, overcast, no heat, no shimmer and moderate wind.
- \*4 When automatic atmospheric correction is on, the EDM error is 10ppm in prism and reflector sheet mode.
- \*5 EDM measuring time is determined in good conditions. It may takes longer than usual to measure the distance exceeding 4000m in prism mode and 300m in reflectorless mode.
- \*6 Quick mode, which functions with prism and reflector sheet, is effective only under normal mode(1mm) and up to 500m.
- \*7 In addition to dual-axis correction in the (X) and (Y) direction, mechanical error in the instrument is corrected.
- \*8 Number of points to be recorded may vary by usage.

  Maximum number of point to be recorded per job site: 3000 points

  Maximum number of job file to be recorded: 50 job files

  Maximum data points to be sent from PC to the instrument: 3000 points

#### 13. NOTICE TO THE USER OF THIS PRODUCT

To assure compliance with the Safety standard 21 CFR, Chapter 1., Subchapter J., the U.S. Bureau of Radiological Health requires the following information to be provided to user.:



It can be dangerous to look into the beam with optical equipment such as binoculars and telescopes.

#### 13.1 Specifications of Laser Radiation

- A) The EDM module of the R-2500N produces a visible light beam, which is emitted from the telescope objective lens and the centre hole of the instrument base plate. The R-2500N is designed and built to have a laser diode radiating at 620-690nm.
- B) Radiant power

The R-2500N is designed and built to radiate a maximum average radiant power of 4.75mW from the telescope. The user may be subject to this radiation as the beam continues operating until such time that the instrument is turned off.

# 13.2 The following labels are affixed to and must remain attached to this laser product.





#### WARNING

- ⚠ Do not stare into the laser beam directly as this may result in damage to your eyes.
- R-2500N is a Class IIIa (3R) Laser product. Do not look into the laser radiation aperture directly as this may result in damage to your eyes.
- Never use the telescope to view intense light such as direct sunlight or sunlight reflected through a prism as this may result in loss of sight.
  - A) The following Certification label is located near the Plate level: "This laser product is complied with the provisions of 21 CFR 1040. 10 and 1040.11. For a Class IIIa laser product."
  - B) Caution label is located near the exit aperture: "AVOID EXPOSURE. Laser radiation is emitted from this aperture."
  - C) Warning logotype is located on the surface of the telescope: "CAUTION LASER RADIATION DO NOT STARE INTO BEAM"
  - D) Warning label is located near the exit aperture.

## 13.3 Caution to maintain the safety in compliance with the standard

- A) To maintain the safety standard, refrain from any operation, maintenance, or adjustment other than described in this instruction manual.
- B) Operation, maintenance or adjustment other than those specified in this instruction manual may result in hazardous radiation exposure.
- C) Maintenance and repair not covered in this manual must be done by an authorized Pentax dealer.
- D) The Laser beam emission by the Distance measurement can be terminated by Pressing [ESC] key.
- E) Pressing [Laser] key and [F2][LD POINT] key can terminate the laser beam emission by the laser pointer.
- F) The laser beam emission by the laser plummet can be terminated by pressing laser key.





Measurement Systems Lite

TI Asahi Co.,Ltd.

International Sales Department
4-3-4 Ueno Iwatsuki-Ku, Saitama-Shi
Saitama,339-0073 Japan
Tel, +81-48-793-0118
Fax, +81-48-793-0128
E-mail: international@tiasahi.com









